

INTERLOCKING DECORATIVE EDGING

13834 S. Kostner Ave. Crestwood, IL 60418

EASY INSTALLATION

Step 1

Water the ground where the pound-in edging is to go.



WARNING:
WEAR SAFETY GOGGLES
USER AND BYSTANDER

ADVERTENCIA:
EL USUARIO Y PERSONAS
EN LAS CERCANÍAS DEBEN
USAR GAFAS DE SEGURIDAD

Step 2

Use garden hose or rope to layout desired design.



Step 3

Choose one of two designs to face outward. Start at one end of your design, pound the first piece into the ground using a rubber mallet to the "Grade Level" line.



Step 4

Insert next piece into the hinged connection point sliding straight down. When the new piece is to the point of touching the ground, pound it down to grade level point like previous piece. Continue this step until design is complete.



Step 5

For angular or curved designs it may be easier to slide pieces together, rotate to desired angle. Then pound in to grade level. the ground, pound it down to grade level point like previous piece. Continue this step until design is complete.

