

DIAMOND LOK PAVER RESTRAINT

ValleyView[®] Industries

13834 S. Kostner Ave. Crestwood, IL 60418

EASY INSTALLATION

Step 1

Install Pavers



WARNING:
WEAR SAFETY GOGGLES
USER AND BYSTANDER

ADVERTENCIA:
EL USUARIO Y PERSONAS
EN LAS CERCANÍAS DEBEN
USAR GAFAS DE SEGURIDAD

Step 2

Slide the bottom section of Diamond-Lok up to the sidewall until the edging sidewall is flush with the pavers



Step 3

Install the stakes at each end and approximately every 2 feet by pounding them through the holes provided on an angle facing the pavers.



Step 4

Backfill with soil and sod flush against edging sidewall



This unique and versatile "L" shape paver restraint is comes in six foot (6') lengths. It can be used as a rigid straight piece OR easily converted to use with curves by use of a hand pruner. Use with standard paving stones and patio stones. May also be used as a landscape border around a bedding area with stone/mulch. Extra heavy duty poly anchor stakes are included in order to ensure that you have more than enough to get the job done right

