

# EASY DIAMOND NO DIG EDGING

# ValleyView<sup>®</sup> Industries

13834 S. Kostner Ave. Crestwood, IL 60418

## EASY INSTALLATION

### Step 1

Unravel the coiled edging, used weighted objects to keep down both ends of edging. Not on grass (it will burn the grass)



WARNING:  
WEAR SAFETY GOGGLES  
USER AND BYSTANDER

ADVERTENCIA:  
EL USUARIO Y PERSONAS  
EN LAS CERCANÍAS DEBEN  
USAR GAFAS DE SEGURIDAD

### Step 2

Sink stake through the edging every 3ft at a 45 degree angles



### Step 3

Backfill and pat down firmly



### Step 4

Enjoy a beautiful landscape

