BENDER BOARD EDGING



13834 S. Kostner Ave. Crestwood, IL 60418

EASY INSTALLATION

WARNING:

WEAR SAFETY GOGGLES
USER AND BYSTANDER

ADVERTENCIA:
EL USUARIO Y PERSONAS
EN LAS CERCANÍAS DEBEN
USAR GAFAS DE SEGURIDAD

Step 1

Use garden hose or rope to provide a guide for digging the area of installation.



Step 3

Dig the trench with a flat spade shovel. The depth of the trench depends on how deep you want the bender board. It is recommended that at least 80% of the bender board be submerged below soil line. In areas where there is winter frost heave.



Step 2

Wet area with water to soften soil. This will allow for easier digging. The amount of water needed depends on the particular soil in your geographic region.



Step 4

Hammer in anchor stakes every four feet. Where it is needed to piece together two lengths of bender board, overlap both pieces of bender board.



