

# ROYAL DIAMOND PROFESSIONAL EDGING

# ValleyView<sup>®</sup> Industries

13834 S. Kostner Ave. Crestwood, IL 60418

## EASY INSTALLATION

### Step 1

For Easier installation, unroll edging on pavement and let warm up for a few hours.  
NOT on grass (it could burn the grass)



WARNING:  
WEAR SAFETY GOGGLES  
USER AND BYSTANDER

---

ADVERTENCIA:  
EL USUARIO Y PERSONAS  
EN LAS CERCANÍAS DEBEN  
USAR GAFAS DE SEGURIDAD

### Step 2

Use a garden hose or marking paint to mark the area where the edging is to be installed



### Step 3

Use a flat spade shovel to dig a 4" trench. Make sure any utility lines are identified before digging



### Step 4

Use either metal or plastic anchor stakes and hammer in at a 45 degree angle through the sidewall of the edging



### Step 5

The design will dictate how many anchor stakes are needed. For straight, slightly curved designs, stakes every four feet should be sufficient. For designs that are circular, stakes every two feet are recommended. Backfill with your chosen bedding material; mulch, stone, etc.

