



# INNOVATIVE EDGING

THE NEXT GENERATION NO DIG EDGING...NO BEAD

Patent # US D850,661

Manufactured by



**ValleyView**  
Industries  
Setting the Landscape Industry Standard

13834 S. Kostner Ave. Crestwood, IL 60418

THESE INSTRUCTIONS FOR ALL COLORS AND ALL SIZES OF INNOVATIVE NO DIG EDGING

## Step 1

Unravel on pavement one day in advance of installation. Put weight source on each end.



## Step 2

Place edging on level soil, with tabs/feet facing towards planting bed.



## Step 3

Use anchor nails every 3 ft. Use extra nails on curves. Secure fabric directly to tab/feet.



## Step 4

Backfill with mulch or other ground cover as desired.



### Need additional 9" nails?

Order from the site you purchased this product OR go to [valleyviewind.com/poly-anchor-nails/](http://valleyviewind.com/poly-anchor-nails/)



Edge Planting Beds



The foot design of our product allows for the use of other type of anchor stakes



Use Around Trees



Made in USA

## We would like to hear from you!

Go online to the website that you purchased the product from and review our product. Also, tell us what you think about our product. We are looking for a five-star review, your opinion counts! We would love to see your project, send your photos to [info@valleyviewind.com](mailto:info@valleyviewind.com)

[www.valleyviewind.com](http://www.valleyviewind.com)