



EASY DIAMOND EDGING

Manufactured by



ValleyView
Industries
Setting the Landscape Industry Standard

13834 S. Kostner Ave. Crestwood, IL 60418

EASY INSTALLATION

PRE-INSTALLATION: Lay out on pavement in sun well in advance of installing.

Step 1

Unravel on pavement one day in advance of installing.



WARNING:
WEAR SAFETY GOGGLES
USER AND BYSTANDER

Step 2

You may choose to attach landscape fabric using anchor stakes in conjunction with tabs.



NEED ADDITIONAL
9" STAKES?

Go to the website you ordered this product from or go to www.valleyviewind.com/poly-stakes/



Step 3

Hammer in stakes every 3 feet through provided holes at a 45° angle. Use extra stakes on curves.

Step 4

Backfill with mulch or other ground cover as desired.

Create a polished look.

Four angular connector options.

Go to www.valleyviewind.com/corner-connector-kit/



Made in USA

We would like to hear from you!

Go online to the website that you purchased the product from and review our product. Also, tell us what you think about our product. We are looking for a five-star review, your opinion counts! We would love to see your project, send your photos to info@valleyviewind.com

www.valleyviewind.com